



VACARDA DESIGN

## **Pliable Plaster Sheet/Fresco**

### **Care & Maintenance Advice**

#### **CLEANING:**

- To remove dust, use a dry, non-fluff cloth or duster.
- To remove occasional markings, use a soft pencil eraser.
- To remove dirt, use a slightly damp, non-fluff cloth and gently rub the patch of dirt to remove it.

#### **MAINTENANCE:**

- If used in steamy, wet areas, i.e., bathrooms and kitchens, reseal the surface once or twice a year as needed.
- If used in high traffic areas where the sheet is touched often, re-apply wax once or twice a year as needed.
- If cracks appear or if the sheet is snapped before you apply it to a wall, lay it flat on the floor and put a heavy, flat weight on the damaged area for a few days. Spraying the damaged area with clean water will help a rigid, older plaster surface heal.
- If cracks appear while your sheet is on the wall, depending on their size, you might not need to do anything. The cracks only appear in the top surface layer while the woven backing remains undamaged. If your sheet was applied to a wall evenly, its integrity will not be affected. For your peace of mind, and if the plaster sheet is used in steamy areas, you can apply a little wax or sealant to the affected area to prevent moisture penetrating the backing.
- If you decide to move your sheet or tapestry, take it off the wall (follow the removal instructions) and lay it flat on the floor for several hours or for as long as is required for it to take a flat shape. The plaster has a good memory and needs to flatten out before it's back on a roll. Inspect the surface for hairline cracks and test the rigidity of the sheet. To soften the sheet, spray it lightly with clean water and let it rest for at least half a day before you put it on a roll.

#### **OTHER INSTRUCTIONS:**

- [Application instructions](#)
- [Removing Instructions](#)
- [Packing instructions](#)